

INSTALLATION AND MAINTENANCE INSTRUCTIONS PRESSURE REDUCING VALVES P15SS

GENERAL

- These instructions must be carefully read before any work involving products supplied by VALSTEAM ADCA ENGINEERING S.A. is undertaken.
- The installation procedure is a critical stage in a life of a valve and care should be taken to avoid damage to the valve or equipment.
- Reducing valves are designed to give accurate control of down-stream pressures. They give their maximum performance only when the equipment associated with them is correctly sized and installed in accordance with our recommendations.

Warning!

- If malfunction of any other equipment or system operation failure may result in a dangerous overpressure, over temperature or even vacuum condition, a safety device must be included in the system to prevent such situations.
- At start up, the presence of small particles in the fluid (dirt, scale, weld splatters, etc) may cause an imperfect closure of the seat. If this occurs, proceed to an accurate cleaning.
- Do not touch the equipment without appropriate protection during working operation because it may conduct heat if the used fluid is at high temperature.
- Before starting maintenance be sure that the equipment is not pressurized or hot.
- The equipments must be used within the working temperature and pressure limits laid down for them, otherwise they may fail (refer to nameplate and/or IS- Information Sheet).
- Do not remove the nameplate attached to the equipment. Serial number and other useful information is stamped on it.
- The valve is not suitable for oxygen service.

INSTALLATION



ATTENTION

- Prior to install check that the product is suitable for the intended application: materials and pressure/temperature ratings.
- Before to install remove plastic covers placed on flanges or connection ends. The equipment has an arrow or Inlet/Outlet designations. Be sure that it will be installed on the appropriate direction.
- Take care with jointing material to ensure that none may be permitted to block or enter the valve.
- Reducing valves are recommended to be fitted with the centre line of the valve in a vertical position to ensure that the best results are obtained.
- An ADCA pipeline strainer should be installed upstream of the valve to protect from dirt which could damage the valve or cause mal-functioning.
- The reducing valve pipework should be properly supported and free from strain and it should not be subjected to undue surges of pressure.

For installations where gas and condensate can be present, we strongly recommend that the reducing valve is positioned where condensation is unable to collect or that, alternatively, separators and steam traps are fitted so that the pipework drains correctly. The start up condition should be considered.

Installation area requirements:

- The installation area should have easy access and provide enough space for maintenance and removing operations.
- The installation area should have the necessary firing system to prevent damage of the equipment due to over temperature/pressure cause by fire.

MAINTENANCE

- We recommend that the pressure reducing valves to be serviced as necessary. Pressure reducing valves should be checked periodically (at least yearly), to verify that they are operating correctly and to clean the internal parts and screen (if any).
- When reassembling make sure that all gasket faces are clean and always use a new gasket. Tighten cover bolts uniformly in a diagonal sequence.
- Valves in store for long periods should have their adjusting spring relaxed.
- For further information refer to the relevant P15SS brochure or consult our Sales Office.

LIMITING CONDITIONS	
Body design conditions	PN100
Maximum upstream pressure (air)	50bar
Maximum upstream pressure (steam)	25bar
Maximum downstream pressure	15bar
Minimum downstream pressure	0,2bar
Maximum design temperature*	260°C
Maximum reducing ratio	40:1
Max.hydraulic factory valve body test	24 bar

*Op. Temp. depending on the type os seals and diaphragm used

Pressure ranges (bar)				
Spring Nr.	1	2	3	4
P15SS	0,2-1,5	0,3-3	0,8-8	1,5-15

It is preferable to select a range spring where the desired reduced pressure is at upper end of range.

Recommended limit of operation (°C)			
EPDM (E)	NBR (N)	VITON (V)	PTFE (T)
130°	95°	180°	180°

USEFUL NOTES ON VALVE AND PIPE SIZING


If the flow is unknown it's possible to estimate it based on pipe size or equipment heat requirements - please consult.

CE MARKING (PED - European Directive 97/23/EC)	
PN100	Category
DN8 to DN15	SEP - art. 3, paragraph3

PARTS LIST FOR P15SS PRESSURE REDUCING VALVES

CODE	DESIGNATION	VALVE SIZE DN	POS.NR.	QTY.
VR.9305.008	Diaphragm rubber / teflon	1/4" - 1/2"	10, 11	1 set
VR.9306.008	Diaphragm st.steel	1/4" - 1/2"	10	1 set
VR.9305.108*	Valve plug, spring, gasket	1/4" - 1/2"	3, 4, 5, 6, 7, 8, 9	1 set
VR.9305.308	Regulating spring 0,2-1,5bar	1/4" - 1/2"	15	1 set
VR.9305.408	Regulating spring 0,3-3bar	1/4" - 1/2"	15	1 set
VR.9305.508	Regulating spring 0,8-8bar	1/4" - 1/2"	15	1 set
VR.9305.608	Regulating spring 1,5-15bar	1/4" - 1/2"	15	1 set

* Suffix : P-PTFE ; N - NBR ; E - EPDM ; V - Viton



ATTENTION

- **LOSS OF WARRANTY:** Total or partial disregard of above instructions involves loss of any right to warranty.